


# Update Mechanical Defrost Timer


## Step 1: Remove mechanical timer:

Remove two screws and pull off the timer from the main PCB board.



## Step 2: Install electronic timer:

Align the electronic timer over the mechanical timer and insert 5 taps into Y-shape connectors by pushing down and finally install two screws.



**MaxTronic Technologies LLC**

[www.maxtronictech.com](http://www.maxtronictech.com) Phone: (704)707-4501 E-mail: sales@maxtronictech.com